Quick Start

Need more help? Go to **APPS > Device Help.**

AT&T Vision Projector

How To Use Your AT&T Vision Projector

Hotspot Widget

Turn the hotspot on or off, and see the network name, password, and number of connected devices.

Projector Widget

Turn the projector on or off, adjust the brightness, or change the source.



Projector Floating Button

Turn the projector on or off and adjust settings while presenting. Press and drag to move it.

Kickstand

Raise the height of the projector.

Manage Your Mobile Connection

If your AT&T service was activated at the time of purchase, you will automatically connect to the mobile network.

AT&T AllAccess

To activate service:

① Tap **Activate** on the AllAccess tile on the home screen.
② Follow the on-screen steps to activate a data plan.

Once service is activated, the AT&T AllAccess widget displays data used while you are connected to the mobile network.

To monitor data usage:

- View plan and data usage details.*
- Enable mobile hotspot to share your Internet connection.**
- View free AT&T Wi-Fi® Hot Spots in your vicinity.



* Actual billed usage can be higher than estimated data usage displayed on the usage meter. For example, actual billed usage may be higher when: part of a shared data plan such as Mobile Share; multiple users with different log in credentials using the same device; traveling internationally or outside AT&T's network; using the SIM card with another device; or, using a tethered handset. Unlimited Wi-Fi usage on AT&T's entire national Wi-Fi network is included at no additional charge with a qualifying data plan. Access includes AT&T Wi-Fi Basic. Restrictions apply. See www.attwifi.com for details. The name "attwifi" will appear in the Wi-Fi network list when available.

**Req's Mobile Share Value or a min. DataPro 5GB plan. Devices connected to a Mobile Hotspot use data from your plan. Overage charges apply if exceed monthly data allowance. Number of devices you can connect depends on your device. Performance varies based on number of devices connected & other factors. If you do not use a password, others will be able to use your Mobile Hotspot. Visit a store or att.com to learn more.

Project Saved Files

Tap **APPS > File Manager**.



If the projector is off, tap the floating projector button.


Turn projector on or off.
Turn auto focus off or on.
Adjust projector brightness.
Projector off
Auto Focus
Projector Brightness
Floating button will hide during full screen projection only or when disabled.
Tap to toggle On/Off

NOTE: Insert the USB drive into the USB port or insert a microSD™ card into the microSD card slot, both located on the back of the device.

Project Using HDMI Cable

Easily project content from an HDMI-capable device.

① Connect your AT&T Vision Projector to an HDMI-capable device with the supplied HDMI cable and turn the AT&T Vision Projector on.
② Tap on the Projector tile on the home screen to turn on the projector.
③ Tap **HDMI** on the Projector tile.
④ On your HDMI-capable device, choose the content you want to display.





Project with Miracast®

Project media wirelessly from a Miracast-capable device to the AT&T Vision Projector.

① Tap on the Projector tile on the home screen to turn on the projector.
② Tap **Miracast** on the Projector tile.
③ Open and enable Miracast or other Wi-Fi display app on your smartphone. Select **MF97B** from the list of available devices.
④ Tap **Accept** on your AT&T Vision Projector.
⑤ On your Miracast capable device, choose the content you want to display.





Mobile Hotspot



Mobile Hotspot Settings



NOTE: When mobile hotspot is enabled, you will be disconnected from all Wi-Fi networks and can only access the Internet with mobile data service.

Block Mobile Hotspot Access

To prevent a device from reconnecting to the mobile hotspot, add it to the hotspot's blocked list.

① On the home screen, tap the **Hotspot widget > Manage users**.

② Select the device you want to block (scroll down to see more connected devices).

③ Note the **MAC address** (you will need to enter this on a separate screen).

④ Turn Hotspot **Off**.

⑤ Tap the **Hotspot widget > Manage users > Block devices**.

⑥ Check **Block users**.

⑦ Select **ADD NEW** to enter MAC address you wish to block.



Transfer Files with the Mobile Hotspot

Share pictures, music, videos, and other types of files.

① Before you begin, make sure you are connected to AT&T Vision Projector's mobile hotspot.

② On your AT&T Vision Projector, tap **SETTINGS > Network > File Share**.

③ Tap OFF.

④ Connect the device you would like to share files with to the AT&T Vision Projector's mobile hotspot.

⑤ Open the connected device's browser, enter **http://attwifimanager** then enter the password shown on the AT&T Vision Projector's File Share screen.



Work with Tabs

You can customize the AT&T Vision Projector interface by adding or removing tabs.



NOTE: Some default tabs can't be deleted or renamed.

Insert a microSD™ Card or microSIM Card



Turn the projector upside down before you open the microSD or microSIM card slots (microSD card sold separately).


Push the point of the microSIM/ microSD pin into the hole on the microSD card slot.
Place the microSD card in the tray making sure it is properly oriented.

NOTE: The microSIM card is already installed. If you need to swap microSIM cards, the process is similar to microSD card installation.

Find More Information

Need More Help?

- On your device: **APPS** > **Device Help**
- On the web: **att.com** > **DeviceHowTo**

Manage Your Account

- On the web: **att.com/MyATT**
  Note: You can also suspend service if your device is stolen.

Give us a Call

- 800.331.0500
- 611 from any AT&T wireless phone

Accessories

- att.com/Wireless Accessories
- Visit your AT&T store

Package Contents: AT&T Vision Projector, Lithium polymer battery, microSIM card (pre-installed), microSIM/microSD pin, Wall adapter and cable, HDMI cable, Carrying case
Note: Use only the included charger and cable with your device.

Product meets FCC Radio Frequency Exposure Guidelines – FCC IDSRQ-MF97B. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Google and Android are trademarks of Google, Inc. microSD logo is a trademark of SD-3C, LLC.

© 2015 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property and/or AT&T. All other marks contained herein are the property of their respective owners.

Printed in China

P/N 079584506995